











## T1610 Install Instruction (拆裝說明書)

STEP 01	STEP 02	STEP 03	STEP 04	STEP 05
				
<p style="text-align: center;">拆下蓋螺絲 Take apart screw of the bottom chassis</p>	<p style="text-align: center;">拆卸HDD支架 Take apart HDD bracket</p>	<p style="text-align: center;">HDD鎖支架 HDD screw the bracket</p>	<p style="text-align: center;">鎖HDD支架 Screw the HDD bracket</p>	<p style="text-align: center;">HDD插電源及訊號線 HDD Install the power/data cable</p>
STEP 06	STEP 07	STEP 08	STEP 09	STEP 10
				
<p style="text-align: center;">拆開導熱片上膠膜 Take off sticker above the thermal pad</p>	<p style="text-align: center;">裝主板 Install the M/B</p>	<p style="text-align: center;">電源訊號線插於主機板 Insert the power/data cable in M/B</p>	<p style="text-align: center;">鎖下蓋螺絲 Screw the bottom chassis</p>	<p style="text-align: center;">成品檢測 Final Goods testing</p>